3-Colour Display

Digital Flow Switch

(F RoHS

New

Applicable fluid Dry air, N2


IP65



* 2-row display of main screen and sub screen







Expanded flow range


Wide range of flow measurement with one product

Flow ratio

Instantaneous flow rate (Main screen) Set value

(Sub screen)

* Rated flow ratio is 10: 1 for current PF2A



Setting resolution






Series PFMC

Compact, Space saving

Compared with the current PF2A,





CAT.EUS100-115A-UK


3-Colour Display Digital Flow Switch Series PFMC



Functions (Pefer to pages 10 and 11 for details.)


- Output operation
- Display colour
- Reference condition
- Setting of response time
- Display mode
- Selection of display on sub screen
 Peak/Bottom value display
- External input function
- Keylock function Accumulated value hold Error display function
- Forced output function
- Analogue output free range function
- Selection of display OFF mode
- Orientation correction function

Installation example



Bypass structure

Bypass structure with protruding part at the main piping, reduces the contact of moist air with the sensor, reducing degradation of the sensor and maintaining accuracy.




Response time


Can be selected from 50 msec. (0.05 sec.)/0.5 sec./1.0 sec./2.0 sec.

Grease-free

Response time can be set depending on application.

Applications







Example of recommended pneumatic circuit



Micro mist separator Flow switch AMD/AFD **PFMC**

Digital flow switch to save energy!

Flow control is necessary for promoting energy saving in any application. Saving energy starts from numerical control of the flow consumption of equipment and lines and clarification of the purpose and effect.

- Digital display allows visualisation.
- 3-colour/2-screen display, Improved visibility
- Remote control is possible with accumulated pulse.









Flow Switch Flow Rate Variations





Flow Switch Variations/Basic Performance Table




(3-Colour Display)

Digital Flow Switch







Note 4) Each option is not assembled with the product, but shipped together.

Option/Part No.

When only optional parts are required, order with the part number listed below.

Part no.	Option	Note
ZS-40-A	Lead wire and M8 connector	Length: 3 m
ZS-42-A	Bracket	Mounting screw for PFMC7501/7102 (M3 x 5, 2 pcs.)
ZS-42-B	Bracket	Mounting screw for PFMC7202 (M3 x 5, 2 pcs.)



Specifications

For Flow Switch Precautions, refer to "Handling Precautions for SMC Products" on www.smc.eu. For Specific Product Precautions, refer to the Operation Manual on www.smc.eu.

	Model		PFMC7501	PFMC7102	PFMC7202				
El:u	Applicable f	luid	Dry air, № (Air quality grade is JIS B 8392-1 1.1.2 to 1.6.2, ISO 8573-1 1.1.2 to 1.6.2.)						
Fluid		rature range	(Air quality grade	0 to 50 °C	3-1 1.1.2 to 1.6.2.)				
	Detection m			Thermal type					
	Rated flow r		5 to 500 l/min 10 to 1000 l/min 20 to 2000 l/min						
	Set flow	Instantaneous flow	5 to 525 I/min	10 to 1050 l/min	20 to 2100 l/min				
	rate range Accumulated flow		0 to 999,999,990 L						
Flow		Instantaneous flow		1 l/min					
		Accumulated flow		10 L					
	(Pulse width =		1 l/pulse	<u> </u>	pulse				
		e hold function Note 1)	I	nterval of 2 or 5 minutes can be selected	d.				
	Rated press			0 to 0.8 MPa					
Pressure	Proof press Pressure los			1.2 MPa					
		acteristics Note 2)	+5	Refer to "Pressure Loss" graph. 5 % F.S. (0 to 0.8 MPa, 0.6 MPa reference	20)				
	Power supp			12 to 24 V DC ±10 %	56)				
Electrical				Ripple (p-p) 10 % or less					
	Current con Protection	sumption		55 mA or less Polarity protection					
	Display acci	uracv		±3 % F.S.					
		tput accuracy		±3 % F.S.					
Accuracy	Repeatabilit		±1 % F.S. (±	2 % F.S. when response time is set to 0	.05 seconds.)				
	Temperature	characteristics		±5 % F.S. (0 to 50 °C, 25 °C reference)					
	Output type			NPN open collector PNP open collector					
	Output mod	е	Select from Hysteresis, Window	v comparator, Accumulated output or Ac	cumulated pulse output modes.				
	Switch oper	ation	Select from Normal or Reversed output.						
	Maximum lo		80 mA						
Switch output		voltage (NPN only)	28 VDC						
	Internal volt			output type: 1 V or less (at load current 8					
	(Residual v			utput type: 1.5 V or less (at load current om 0.05 sec., 0.1 sec., 0.5 sec., 1 sec.,					
	Hysteresis N		Selectii	Variable from 0	or 2 sec.				
	Protection		Short circuit protection						
	Output type		Voltage output: 1 to 5 V, Current output: 4 to 20 mA						
		Voltage output	Output impedance: Approx. 1 kΩ						
Analogue output Note 5)	Impedance	Current	Maximum load impedance at power supply voltage 24 V: 600 Ω ,						
· · · · · · · · · · · · · · · · · · ·		output	at power supply voltage 12 V: 300 Ω						
	Response ti	Note 6)	Minimum load impedance: $50~\Omega$ Linked with the response time of the switch output.						
	External inp			0.4 V or less (Reed or Solid state) for 30					
External input Note 7)	Input mode			mulated flow external reset, Peak/Botton					
	Reference co	ondition Note 8)		t from Standard condition or Normal cor					
	Unit Note 9)	Instantaneous flow		l/min, cfm (ft ³ /min)					
	Offic and	Accumulated flow		L, ft ³					
	Displayable range	Instantaneous flow	-25 to 525 l/min (Displays [0] when value is within -4 to 4 l/min range.)	-50 to 1050 l/min (Displays [0] when value is within -9 to 9 l/min range.)	$-100\ to\ 2100\ l/min$ (Displays [0] when value is within –19 to 19 l/min range.)				
Display		Accumulated flow		0 to 999,999,999 L					
Display		Instantaneous flow		1 <u>I/min</u>					
	aispiay unit	Accumulated flow	100.0	10 L					
	Display		LCD, 2-screen display (Main screen/Sub screen) Main screen: Red/Green, Sub screen: White						
			Main screen: 4 digits, 7 segment, Sub screen: 6 digits, 11 segment						
	Indicator LE	:D	LED ON when switch output is ON. (OUT1/OUT2: Orange)						
	Enclosure Withstand v	oltago	IP65						
Environmental	Insulation re		250 V AC for 1 minute between terminals and housing 2 MΩ or more (50 V DC measured via megohmmeter) between terminals and housing						
		perature range	Operation: 0 to 50 °C, Storage: –10 to 60 °C (No condensation or freezing)						
Operating humidity range				torage: 35 to 85 % RH (No condensatio					
Standard				CE, RoHS					
Piping specifications				T 1/2, G 1/2	Rc 3/4, NPT 3/4, G 3/4				
Materials of parts	in contact wi		Stainless st	eel 304, PPS, Aluminum alloy, HNBR, S	i, Au, GE4F				
	Piping	Rc thread	16	60 g	240 g				
Waight	specification	ns NPT thread							
Weight	Lead wire	G thread	17	<u>'0 g</u> +80 g	245 g				
	Bracket		+2	#80 g	+30 a				
			12	- 3	+30 g				

Note 1) When using the accumulated value hold function, use the operating conditions to calculate the product life, and do not exceed it. The maximum access limit of the memory device is 1 million cycles. If the product is operated 24 hours per day, the product life will be as follows:

- 5 min interval: life is calculated as 5 min x 1 million = 5 million min = 9.5 years • 2 min interval: life is calculated as 2 min x 1 million = 2 million min = 3.8 years If the accumulated flow external reset is repeatedly used, the product
- Note 2) Do not release the OUT side piping port of the product directly to the atmosphere without connecting piping. If the product is used with the piping port released to atmosphere, accuracy may vary.

life will be shorter than calculated life.

Note 3) The time from when the flow is changed by a step input (when the flow

rate changes from 0 to the maximum flow instantaneously) until the switch output turns ON (or OFF) when set at 90 % of the rated flow rate.

- Note 4) If the flow fluctuates around the set value, the width for setting more than the fluctuating width needs to be set. Otherwise, chattering will occur.
- Note 5) Setting is only possible for models with analogue output.
- Note 6) The time from when the flow is changed as a step input (when the flow rate changes from 0 to the maximum flow instantaneously) until the analogue output reaches 90 % of the rated flow rate.
- Note 7) Setting is only possible for models with external input.
- Note 8) The flow rate given in the specification is the value at standard condition.
- Note 9) Setting is only possible for models with the unit selection function.



3-Colour Display Digital Flow Switch Series PFMC

Flow Range


Model				Flow range		
Model	-100	l/min 0 l/min	200 l/min	500 l/min	1000 l/min	2000 l/min
PFMC7501	-	5 l/min 5 l/min –25 l/min		500 l/min 525 l/min 525 l/min		
PFMC7102		10 l/min 10 l/min l/min			1000 l/min 1050 l/min 1050 l/min	
PFMC7202	-100 l/min	20 l/min 20 l/min				2000 l/min 2100 l/min 2100 l/min
			•	Rated flow r	ange Set flow rate ran	nge Displayable range

Analogue Output

Flow/Analogue Output


		•	
	Α	В	С
Voltage output	1 V	1.04 V	5 V
Current output	4 mA	4.16 mA	20 mA

Model		Maximum flow of rated flow range	
PFMC7501	5 l/min	500 l/min	
PFMC7102	10 l/min	1000 l/min	
PFMC7202	20 l/min	2000 l/min	




Pressure Loss (Reference Data)


PFMC7501 (for 500 I/min)



PFMC7102 (for 1000 I/min)





PFMC7202 (for 2000 I/min)



IN Side Straight Piping Length and Accuracy (Reference Value)

- The piping on the IN side must have a straight section of piping with a length of 8 cm or more. If a straight section of piping is not installed, the accuracy can vary by approximately $\pm 2\%$ F.S.
- * "Straight section" means a part of the piping without any bends or rapid changes in the cross sectional area.
- When the PFMC7501 or 7102 is connected to tubing, use a tube I.D. 9 mm or more just before the product. The accuracy can vary by approximately ±2 % F.S. when such tubing is not used.





Internal Circuits and Wiring Examples

NPN (2 outputs) type PFMC7□□□-□□-A□-□□□

Brown DC (+)

Black OUT1


White OUT2

Blue DC (-)

Max. applied voltage: 28 V, Max. load current: 80 mA, Internal voltage drop: 1 V or less

NPN (1 output) + Analogue (1 to 5 V) output type PFMC7□□□-□□-C□-□□□

NPN (1 output) + Analogue (4 to 20 mA) output type PFMC7




Max. applied voltage: 28 V, Max. load current: 80 mA, Internal voltage drop: 1 V or less

C: Analogue output: 1 to 5 V
Output impedance: 1 kΩ
D: Analogue output: 4 to 20 mA


Max. load impedance: 600 Ω Min. load impedance: 50 Ω

NPN (1 output) + External input type PFMC7




Max. applied voltage: 28 V, Max. load current: 80 mA, Internal voltage drop: 1 V or less External input: input voltage 0.4 V or less (reed or solid state input) for 30 msec. or longer

External input. Input voltage 0.4 v or loss (ross or soils state input) for so mo




PNP (2 outputs) type



Max. load current: 80 mA, Internal voltage drop: 1.5 V or less

PNP (1 output) + Analogue (1 to 5 V) output type PFMC7□□□-□□-Ε□-□□□

PNP (1 output) + Analogue (4 to 20 mA) output type PFMC7□□□-□□-F□-□□□




Max. load current: 80 mA, Internal voltage drop: 1.5 V or less

E: Analogue output: 1 to 5 V Output impedance: 1 kΩ F: Analogue output: 4 to 20 mA

Max. load impedance: 600 Ω Min. load impedance: 50 Ω

PNP (1 output) + External input type PFMC7



Max. load current: 80 mA, Internal voltage drop: 1.5 V or less

External input: input voltage 0.4 V or less (reed or solid state input) for 30 msec. or longer


PNP (2 outputs) type

PFMC7000-00-B0-00

PNP (1 output) + Analogue output type

PFMC7000-00-F0-000

PNP (1 output) + External input type PFMC7




50 ms

50 ms

3-Colour Display Digital Flow Switch $Series\ PFMC$

Construction/Fluid Contact Parts





Component Parts


No.	Description	Material	Note
1	Sensor body	PPS	
2	Gasket	HNBR	
3	Flow rectifier	Stainless steel 304	
4	Sensor chip	Silicon	
5	Printed circuit board	GE4F	
6	Gasket	HNBR	
7	Body	Aluminium alloy	Anodised
8	Mesh	Stainless steel 304	
9	Spacer	PPS	
10	O-ring	HNBR	
11	Holder	Stainless steel 304	
12	Type C retaining ring	Stainless steel 304	


Dimensions

PFMC7501/7102/7202










Symbol	Port size	Α	В	D	E	F	Н	К	L	N
PFMC7501/7102	Rc 1/2, NPT 1/2	70	30	60.6	41.2	15	14	26	18	13.6
PFMC7202	Rc 3/4, NPT 3/4, G 3/4	90	35	66.1	46.7	17.5	24	31	28	16.8
PFMC7501/7102	G 1/2	76	30	60.6	41.2	15	14	26	18	13.6

Symbol	Bracket dimensions				
Model	S	Т	U	V	W
PFMC7501/7102	24	22	32	40	50
PFMC7202	30	30	42	48	58

Lead wire and M8 connector



Pin no.	Pin no. Pin name		
1	DC (+)	Brown	
2	OUT2	White	
3	DC (-)	Blue	
4	OUT1	Black	

Note) 4-wire type lead wire and M8 connector used for the PFMC7 series. Note) Refer to the Operation Manual in our website for wiring.

Cable Specifications

Conductor	Nominal cross section	AWG23	
	Outside diameter	Approx. 0.7 mm	
Insulator	Material	Heat resistant PVC	
	Outside diameter	Approx. 1.1 mm	
	Colour	Brown, White, Black, Blue	
Sheath Material		Heat and oil resistant PVC	
Finished outside diameter		Ø 4	



Series PFMC Function Details

■ Output operation

The output operation can be selected from the following:

Output (hysteresis mode and window comparator mode) corresponding to instantaneous flow, or output (accumulated output and pulse output) corresponding to accumulated flow.

Note) At the time of shipment from the factory, it is set to hysteresis mode and normal output.

■ Display colour

The display colour can be selected for each output condition. The selection of the display colour provides visual identification of abnormal values. (The display colour depends on OUT1 setting.)

Green for ON, Red for OFF
Red for ON, Green for OFF
Red all the time
Green all the time

■ Reference condition

The display unit can be selected from standard condition or normal condition.

Standard condition: Flow rate converted to a volume at 20 °C and 1 atm (atmosphere)

Normal condition: Flow rate converted to a volume at 0 °C and 1 atm (atmosphere)

■ Display mode

The display mode can be selected from instantaneous flow or accumulated flow.

Instantaneous flow display

Accumulated flow display

■ Response time

The response time can be selected to suit the application. (Default setting is 1 second.)

Abnormalities can be detected more quickly by setting the response time to 0.05 seconds.

The effect of fluctuation and flickering of the display can be reduced by setting the response time to 2 seconds.

0.05 sec. 0.1 sec. 0.5 sec.

1 sec. 2 sec.

■ External input function

This function can be used only when the optional external input is present. The accumulated flow, peak value and bottom value can be reset remotely.

Accumulated flow external reset: A function to reset the accumulated flow value when an external input signal is applied.

when an external input signal is applied. In accumulated increment mode, the accumulated value will reset to, and increase from zero.

In accumulated decrement mode, the accumulated value will reset to, and decrease from the set value.

* When the accumulated value is memorised, every time the accumulated flow external reset is activated, the memory device (EEPROM) will be accessed. Take into consideration the maximum number of times the memory device can be accessed, 1 million times. The total of external input times and accumulated value memorising time interval should not exceed 1 million times.

Peak/Bottom reset: Peak and bottom value are reset.

■ Forced output function

The output is turned on/off in a fixed state when starting the system or during maintenance. This enables confirmation of the wiring and prevents system errors due to unexpected output.

For the analogue output type, when ON the output will be 5 V or 20 mA, and when OFF, it will be 1 V or 4 mA.

* Also, the increase or decrease of the flow and temperature will not change the on/off status of the output while the forced output function is activated.

■ Accumulated value hold -

Accumulated value is not cleared even when the power supply is turned off.

The accumulated value is memorised every 2 or 5 minutes during measurement, and continues from the last memorised value when the power supply is turned on again.

The life time of the memory element is 1 million access cycles. Take this into consideration before using this function.

■ Selection of display on sub screen

The display on the sub screen in measuring mode can be set.



Set value display	Accumulated value display	Peak value display
Displays the set value. (The set value of OUT2 cannot be displayed.)	Displays the accumulated val- ue. (The accumulated value of OUT2 cannot be displayed.)	Displays the peak value.
SOURCE ALONS SMITCH (A)	GANC ROW SWITCH	GONC ROWSWICH IN THE CONTROL OF THE
Bottom value display	Line name display	OFF
Displays the bottom value.	Displays the line name. (Up to 6 alphanumeric characters can be input.)	Displays nothing.
GOAC FLOW SWITCH (A)	GSMC FLOW SWITCH (A) SMC_PF (9)	GSAC FLOWSWICH (A)

■ Display OFF mode

This function will turn the display OFF. In this mode, decimal points flash on the main screen. If any button is pressed during this mode, the display reverts to normal for 30 seconds to allow checking of the flow etc.

■ Setting of security code

The user can select whether a security code must be entered to release key lock. At the time of shipment from the factory, it is set such that the security code is not required.

■ Peak/Bottom value display

The maximum (minimum) flow rate is detected and updated from when the power supply is turned on. In peak (bottom) value display mode, this maximum (minimum) flow rate is displayed.


■ Keylock function

Prevents operation errors such as accidentally changing setting values.



■ Analogue output free range function

Allows the flow that generates an output of 5 V or 20 mA to be changed. The value can be changed 10 % of maximum rated flow to maximum display value.



■ Error display function

When an error or abnormality arises, the location and contents are displayed.

Display		Description	Contents	Action	
Er I	Er I		Load current of 80 mA or more is applied to the switch output (OUT1).	Eliminate the cause of the over current by	
Er2		OUT2 over current error	Load current of 80 mA or more is applied to the switch output (OUT2).	turning off the power supply and then turn on it again.	
ннн		Instantaneous flow error	The flow rate exceeds the upper limit of indicated flow rate range.	Decrease the flow rate.	
LLL	LLL		There is a reverse flow equivalent to -5 % or more.	Turn the flow to correct direction.	
(Alternately displays) [999] and [999999].	PFMC7501 PFMC7102 PFMC7202	Accumulated flow error	The flow rate exceeds the accumulated flow rate range.	Clear the accumulated flow rate.	
ErO .					
<u> </u>		System error	Displayed if an internal error has occurred.	Turn the power off and on again.	
Er8					

If the failure cannot be solved after the above instructions are performed, please contact SMC for investigation.







⚠ Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.

Caution indicates a hazard with a low level of risk

which, if not avoided, could result in minor or moderate

Warning indicates a hazard with a medium level of risk **⚠** Warning: which, if not avoided, could result in death or serious

injury.

Danger indicates a hazard with a high level of risk ⚠ Danger: which, if not avoided, will result in death or serious injury. *1) ISO 4414: Pneumatic fluid power - General rules relating to systems. ISO 4413: Hydraulic fluid power - General rules relating to systems. IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements) ISO 10218-1: Manipulating industrial robots - Safety.

⚠ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3.Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation

Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, wichever is first.*2) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular
 - *2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary

If anything is unclear, contact your nearest sales branch.

∕∴Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

Be sure to read "Handling Precautions for SMC Products" (M-E03-3) before using.

SMC Corporation (Europe)

Austria Belgium Bulgaria	≅+43 (0)2262622800 ≅+32 (0)33551464 ≅+359 (0)2807670	www.smc.at www.smcpneumatics.be www.smc.bg	office@smc.at info@smcpneumatics.be office@smc.bg	Lithuania Netherlands Norway	☎+370 5 2308118 ☎+31 (0)205318888 ☎+47 67129020	www.smclt.lt www.smcpneumatics.nl www.smc-norge.no	info@smclt.lt info@smcpneumatics.nl post@smc-norge.no
Croatia	2 +385 (0)13707288	www.smc.hr	office@smc.hr	Poland	* +48 222119600	www.smc.pl	office@smc.pl
Czech Republic	2 +420 541424611	www.smc.cz	office@smc.cz	Portugal	* +351 226166570	www.smc.eu	postpt@smc.smces.es
Denmark	2 +45 70252900	www.smcdk.com	smc@smcdk.com	Romania	2 +40 213205111	www.smcromania.ro	smcromania@smcromania.ro
Estonia	* +372 6510370	www.smcpneumatics.ee	smc@smcpneumatics.ee	Russia	* +7 8127185445	www.smc-pneumatik.ru	info@smc-pneumatik.ru
Finland	2 +358 207513513	www.smc.fi	smcfi@smc.fi	Slovakia	2 +421 (0)413213212	www.smc.sk	office@smc.sk
France	2 +33 (0)164761000	www.smc-france.fr	promotion@smc-france.fr	Slovenia	2 +386 (0)73885412	www.smc.si	office@smc.si
Germany	2 +49 (0)61034020	www.smc.de	info@smc.de	Spain	* +34 902184100	www.smc.eu	post@smc.smces.es
Greece	2 +30 210 2717265	www.smchellas.gr	sales@smchellas.gr	Sweden	2 +46 (0)86031200	www.smc.nu	post@smc.nu
Hungary	* +36 23511390	www.smc.hu	office@smc.hu	Switzerland	* +41 (0)523963131	www.smc.ch	info@smc.ch
Ireland	2 +353 (0)14039000	www.smcpneumatics.ie	sales@smcpneumatics.ie	Turkey	2 +90 212 489 0 440	www.smcpnomatik.com.tr	info@smcpnomatik.com.tr
Italy	2 +39 0292711	www.smcitalia.it	mailbox@smcitalia.it	UK	* +44 (0)845 121 5122	www.smcpneumatics.co.uk	sales@smcpneumatics.co.uk
Latvia	2 +371 67817700	www.smclv.lv	info@smclv.lv		• •	•	