2-Colour Display Digital Pressure Switch








Leakage

x 10⁻¹⁰Pa·m³/s <VCR®- and Swagelok®-fitting compliant>

x 10⁻⁵Pa⋅m³/s

<Threaded type (R, Rc, NPT, G)>

- Sensor and fitting parts are electron-beam welded.
- Choice of VCR® or Swagelok® fitting is available.




Applicable Fluid Examples VCR® and Swagelok® are registered trademarks of Swagelok Company.

- Water
- Hydraulic fluid (JIS-K2213)
- Silicon oil (JIS-K2213)
- Lubricant (JIS-K6301)
- Fluorocarbon

- Argon
- Ammonia
- Carbon dioxide
- Air-containing drainage
- Nitrogen


Applications



Restrictor installed fitting type (-X510) Made to Order

A pressure switch that has a restrictor installed in the fitting is available so that it prevents the sensor from being damaged by water collision with rush inertia. (Refer to page 12 for details.)

ariations



2-color display (LCD)

Can select from 4 indicator patterns of colour combinations.

	ON	OFF
1	Red	Green
2	Green	Red
3	Red	Red
4	Green	Green

SMC PRESSURE RPa

Piping

Rc1/8 (female threaded) is now available.

- R1/4 (M5 female threaded)
- NPT1/4 (M5 female threaded)
- G1/4 (M5 female threaded)
- •Rc1/8

URJ1/4 (VCR® fitting compliant)

TSJ1/4 (Swagelok® fitting compliant)

Output display

It lights when OUT1 or OUT2 outputs.

Convex rubber button

Convex button is adopted and provides IP65 rating. Improved maneuverability and operability.

Lead wire length

2 m (Standard)

3 m (Made to Order)

Output

Analogue current output is newly added.

- Advantageous when it is wired a long distance away.
- It is noise resistant..
- NPN open collector 1 output
- PNP open collector 1 output
- NPN open collector 2 outputs
- PNP open collector 2 outputs
- NPN open collector 2 outputs + Analogue voltage output/Auto-shift switching
- PNP open collector 2 outputs + Analogue voltage output/Auto-shift switching
- NPN open collector 2 outputs + Analogue current output/Auto-shift switching
- PNP open collector 2 outputs + Analogue current output/Auto-shift switching

■ Security code setting······

This ensures that only authorised persons can operate the switch when the key is locked.



Input an arbitrary three-digit value.

* The set-value can be confirmed even when the key is locked.

■ Resolution switching function ······

It prevents minor variation of the indicated value.



(Only the indicated value changes without changing precision.)

■ Power-saving mode ······

Turning off the display can save power consumption. (Power consumption: Max. 18% reduced)



The numerical value disappears and the decimal points blink.

■ MPa/kPa switching function ······

The indication unit for vacuum, compound pressure and positive pressure can be integrated into either MPa or kPa.




Front protection cover Suitable for side-by-side mounting Requires less installation space and panel cutting. Only one opening

Bracket mount Bracket Bracket



2-Colour Display Digital Pressure Switch For General Fluids

Series ZSE80/ISE80



Input/Output

N	NPN open collector 1 output
Р	PNP open collector 1 output
Α	NPN open collector 2 outputs
В	PNP open collector 2 outputs
R	NPN open collector 2 outputs + Analogue voltage output/Auto-shift switching
Т	PNP open collector 2 outputs + Analogue voltage output/Auto-shift switching
S	NPN open collector 2 outputs + Analogue current output/Auto-shift switching
٧	PNP open collector 2 outputs + Analogue current output/Auto-shift switching




Table 1 Made to Order

Symbol	Specifications	
-X500 Note)	Wetted parts: Stainless steel 316L	
-X501	Lead wire length 3 m	
-X510	Restrictor installed fitting	

Note) Not applicable to the rated pressure range 0 to 2 MPa specification. Refer to page 12 for details.

Option

,		
Option	Piping direction	Part no.
	Rear ported	ZS-24-A
Bracket	Rear ported	ZS-24-D
	Bottom ported	ZS-35-A
Panel mount	Rear ported	ZS-35-C
Pariel mount	Bottom ported	ZS-35-B
Donal mount : Front protection cover	Rear ported	ZS-35-F
Panel mount + Front protection cover	Bottom ported	ZS-35-E



Bottom ported

Note) Rear ported only

Rear ported

Specifications

Model			ZSE80 (Vacuum pressure)	ZSE80F (Compound pressure)	ISE80 (Positive pressure)	ISE80H (Positive pressure)
Rated pressure range 0.0			0.0 to -101.0 kPa	-100.0 to 100.0 kPa	-0.100 to 1.000 MPa	-0.100 to 2.00 MPa
Set pressure ra	Set pressure range			-110.0 to 110.0 kPa	-0.105 to 1.100 MPa	-0.105 to 2.20 MPa
Withstand pres	Withstand pressure			500 kPa 2 MPa 4 MPa		
Wetted parts m	naterial		Pressure sensor: Stainless steel 630, Fitting: Stainless steel 304			teel 304
Applicable flui	d			Fluids do not corrode sta	inless steel 630 and 304	ļ
Port size			R1/4, NPT1/4, G1/4*, URJ1/4, TSJ1/4, Rc1/8 Piping direction: Rear/Bottom			
Power supply	voltage		12 to 24 VDC ±10	0%, Ripple (p-p) 10% or I	ess (with power supply p	oolarity protection)
Current consu	mption			45 mA	or less	
			NPI	N 1 output, NPN 2 outputs,	PNP 1 output, PNP 2 out	tputs
	Maximum	load current		80	mA	
Switch	Maximum	load voltage		28 V (at N	PN output)	
output	Residual v	voltage		1 V or less (with loa	d current of 80 mA)	
	Response	time	2.5 ms (with anti-chattering functi	on: 20, 100, 500, 1000, 2	2000 ms)
	Short circ	uit protection		Ye	es	
Repeatability				±0.2% F.5	S. ±1 digit	
Hysteresis	Hysteresis Window c	s mode omparator mode		Variable (0	or above)	
	Voltage	Output voltage (Rated pressure range)	1 to 5 V ±	-2.5% F.S.	0.6 to 5 V ±2.5% F.S.	0.8 to 5 V ±2.5% F.S.
	output	Linearity	±1% F.S. or less			
		Output impedance	Approx. 1 kΩ			
Analogue output		Output current (Rated pressure range)	4 to 20 mA	±2.5% F.S.	2.4 to 20 mA ±2.5% F.S.	3.2 to 20 mA ±2.5% F.S.
	Current	Linearity	±1% F.S. or less		5. or less	
	output	Load impedance	Maximum load impedance: 300Ω (Power supply voltage 12 V) 600Ω (Power supply voltage 24 V) Minimum load impedance: 50Ω			
A				<u> </u>		
Auto-shift inpu	ıτ		Non-voltage input	(Reed or Solid state), Lo		
Display Display accura			3 1/2-digit, 7-segment, 2-color LCD (Red/Green) ±2% F.S. ±1 digit (Ambient temperature of 25 ±3°C)			
Indicator light	icy		Lights up when output is turned ON. OUT1, OUT2: Orange			
Function			Anti-chattering, Zero-out, Key lock function, Auto-preset, Auto-shift, Unit display switching, Power-saving mode			
	Enclosure)		IP		
		temperature range	Operating:	0 to 50°C, Stored: -10 to	60°C (No freezing or co	ndensation)
		humidity range		Operating/Stored: 35 to 8		
Environmental	Withstand		250 VAC for 1 minute between live parts and case			
resistance		resistance			·	
	Vibration	resistance	2 MΩ or more between live parts and case (at 50 VDC Megohmmeter) 10 to 150 Hz if amplitude smaller than 15 mm or acceleration lower than 20 m/s², in X, Y, Z directions, for 2 hours each (De-energised)			,
	Impact resistance		100 m/s ² in X, Y, Z directions, 3 times each (De-energised)			· · · · · · · · · · · · · · · · · · ·
Temperature c	haracteristi	cs		S. (Based on 25C, within		
Lead wire			Oilproof heavy-duty	vinyl cable, 3 cores (N.F 4 cores (A.B 5 cores (R.T	Conductor area:	0.15 mm² (AWG26)
Standarde			` '			
Standards			CE marking, UL/CSA, RoHS compliance			

^{*} G1/4 is available for rear ported only.

Piping Specifications


Model	02	N02	F02	C01	A2	B2
Port size	R1/4	NPT1/4	G1/4	Rc1/8	URJ1/4	TSJ1/4
Weight (Bottom ported)	117 g	118 g	_	114 g	120 g	111 g
Weight (Rear ported)	89 g	90 g	86 g	86 g	92 g	83 g
Leakage	1 x 10 ⁻⁵ Pa·m³/s			1 x 10 ⁻¹⁰	Pa·m³/s	



Analogue Output

Voltage output [V] Indition and on the state of the state





Range	Rated pressure range	Α	В	С
For vacuum pressure	0.0 to -101.0 kPa	10.1 kPa	0	-101.0 kPa
For compound pressure	-100.0 to 100.0 kPa	_	-100.0 kPa	100.0 kPa
For positive	-0.100 to 1.000 MPa	-0.100 MPa	0	1.000 MPa
pressure	-0.100 to 2.00 MPa	-0.100 MPa Note)	0	2.00 MPa

Note) Analogue output is 0.8 [V] or 3.2 [mA] at pressure A.

Descriptions

- 0.6 **B**

Output (OUT1) display (Orange)

Lights up when OUT1 is turned ON.

Output (OUT2) display (Orange)

Lights up when OUT2 is turned ON.

\triangle button

Use this button to select the mode or increase the $\ensuremath{\mathsf{ON}}/\mathsf{OFF}$ set-value.

It is also used for switching to the peak display mode.



Pressure

LCD

Displays the current pressure, set mode, selected display unit, and error code. Always use red or green display; or switch between green and red according to the output. Four different display settings are available.

SET button

Use this button to change the mode or confirm the set-value.


▽ button

Use this button to select the mode or decrease the $\ensuremath{\mathsf{ON}}/\mathsf{OFF}$ set-value.


It is also used for switching to the bottom display mode.

Internal Circuits and Wiring Examples

-N NPN (1 output)




-P PNP (1 output)



Max. 80 mA Residual voltage 1 V or less


-A NPN (2 outputs)



Max. 28V, 80 mA Residual voltage 1 V or less


-B PNP (2 outputs)

Residual voltage 1 V or less




Max. 80 mA Residual voltage 1 V or less

-R NPN (2 outputs) + Analogue voltage output




Max. 28V, 80 mA Residual voltage 1 V or less

-R/-S NPN (2 outputs) + Auto-shift input




Max. 28V, 80 mA Residual voltage 1 V or less

-S NPN (2 outputs) + Analogue current output




Max. 28V, 80 mA Residual voltage 1 V or less

-T PNP (2 outputs) + Analogue voltage output




Max. 80 mA Residual voltage 1 V or less

-T/-V PNP (2 outputs) + Auto-shift input




Max. 80 mA Residual voltage 1 V or less

-V PNP (2 outputs) + Analogue current output



Max. 80 mA Residual voltage 1 V or less

Dimensions





-B2: TSJ1/4


-A2: URJ1/4


Dimensions


ZSE/ISE8 - 02L - N02L C01L C01L A2L B2L



















SMC


Dimensions

With bracket (Rear ported)

• ZS-24-A










With bracket (Rear ported)


• ZS-24-D









With bracket (Bottom ported)








16.3

Dimensions



SMC

Dimensions Panel mount (Bottom ported) 38.6 24.2 □40 7.5 51.2 **Panel-cut dimensions** 36±0.3 36 x n pcs. + 4 x (n pcs. - 1) 36±0.3 36 4 x R3 or less 4 x R3 or less

2-Colour Display Digital Pressure Switch For General Fluids Series ZSE80/ISE80


Function Details

F□ in brackets stand for the function codes. Refer to the operating manual for how to operate and function codes in detail.

A Auto-shift function (F4)

When there are large fluctuations in the supply pressure, the switch may fail to operate correctly. The auto-shift function compensates such supply pressure fluctuations. It measures the pressure at the time of auto-shift signal input and uses it as the reference pressure to correct the set-value on the switch.

Set-value correction by auto-shift function



* Rectified value

When the auto-shift is selected, "ooo" will be displayed for approximately 1 second, and the pressure value at that point will be saved as a rectified value "C_5". Based on the saved rectified values, the set-value Note) of "P_1", "H_1", "P_2", and "H_2" will likewise be rectified.

Note) When an output is reversed, "n_1", "H_1", "n_2", "H_2" will be rectified

Possible Set Range for Auto-Shift Input

	Regulating pressure range	Possible set range
Compound pressure	-110.0 to 110.0 kPa	–220 to 220 kPa
Vacuum pressure	10.0 to -111.0 kPa	121.0 to -121.0 kPa
Docitivo proceuro	-0.105 to 1.100 MPa	-1.205 to 1.205 MPa
Positive pressure	-0.105 to 2.20 MPa	-2.31 to 2.31 MPa

Auto-shift zero


The basic function of auto-shift zero is the same as the function for auto-shift. Also, it corrects values on the display, based on a pressure value of 0, when the auto-shift is selected.

B Auto-preset function (F8)

Auto-preset function, when selected in the initial setting, calculates and stores the set-value from the measured pressure.

The optimum set-value is determined automatically by repeating vacuum and break with the target workpiece several times.

Suction Verification




Formula for Obtaining the Set-Value

P_1 or P_2	H_1 or H_2
P_1 (P_2) = A - (A-B)/4 n_1 (n_2) = B + (A-B)/4	H_1 (H_2) = (A-B)/2

C Precision indicator setting function (F7)

Fine adjustment of the indicated value can be made within the range of $\pm 5\%$ of the read value. The scattering of the indicated value can be eliminated.



Note) When the precision indicator setting function is used, the set pressure value may change ± 1 digit.

D Peak and bottom display function

This function constantly detects and updates the maximum (minimum) value and allows to hold the maximum (minimum) pressure value.

When the (a) (b) buttons are simultaneously pressed for 1 second or longer, while "holding", the hold value will be reset.

E Key lock function

This function prevents incorrect operations such as accidentally changing the set-value.

F Zero-out function

This function clears and resets the zero value on the display of measured pressure.

For the pressure switch with analogue output, the analogue output shifts according to the indication. A displayed value can be adjusted within $\pm 10\%$ F.S. of the pressure when ex-factory.



Function Details

G Error indication function

Error	Error code	Description
rcurrent	Erl	Load current of switch output (OUT1) exceeds 80 mA.
Overcurrent	ErZ	Load current of switch output (OUT2) exceeds 80 mA.
Residual pressure error	Er3	It is still applied with pressure that is ±10% over the atmospheric pressure and the upper limit of the rated pressure range when it is cleared to zero. * After displaying the error code for 1 second, the switch automatically returns to the measuring mode. Due to individual product differences, the setting range varies ±1 digits.
Applied pressure error	HHH	Supply pressure exceeds the maximum set pressure.
App pressu	LLL	Supply pressure is below the minimum set pressure.
Auto-shift error	The value measured at the time of auto-shift inp outside the set pressure range. * After displaying the error code for one second, switch returns to the measuring mode.	
ror	Er 🛚 Internal data error	
System error	Er4	Internal data error
Sy	Er7	Internal data error


H Anti-chattering function (F3)

A large bore cylinder or ejector consumes a large volume of air in operation and may experience a temporary drop in the supply pressure. This function prevents detection of such temporary drops in the supply pressure as an error.

Available response time settings
20 ms, 100 ms, 500 ms, 1000 ms, 2000 ms

<Principle>

This function averages pressure values measured during the response time set by the user and then compares the average pressure value with the pressure set point value to output the result on the switch.



Unit display switching function (F0)

Display units can be switched with this function.

Pressure range		For compound pressure	For vacuum pressure		or pressure
Applicable pressure sensor		ZSE80F	ZSE80	ISE80	ISE80H*
Set pr	essure	-110 to 110 kPa	10 to -111 kPa	-0.1 to 1.1 MPa	-0.1 to 2.2 MPa
28	kPa	0.1	0.1	1	1
[[MPa	_	_	0.001	0.001
GF	kgf/cm ²	0.001	0.001	0.01	0.01
ьЯг	bar	0.001	0.001	0.01	0.01
P5 ,	psi	0.02	0.02	0.1	1
ıπΗ	inHg	0.1	0.1	_	_
ññX	mmHg	1	1	_	_

^{*} ISE80H: Does not indicate the last digit when the pressure is 2.000 MPa or higher.

J Power-saving mode (F9)



The numerical value disappears and the decimal points blink.

Power-saving mode can be selected.

It shifts to the power-saving mode without button operation for 30 seconds. It is set to the normal mode (Power-saving mode is OFF.) when ex-factory. (Decimal points and operation indicator light (only when the switch output is turned ON.) blink in the power-saving mode.)

K Security code setting (F10)



Input an arbitrary three-digit value.

It can be set whether code number input is required or not when key is locked. It is set to input no code number when ex-factory.

^{*} The set-value can be confirmed when the key is locked.

Series ZSE80/ISE80 Made to Order



Please contact SMC for detailed dimensions, specifications, and lead times.

1 Wetted parts: Stainless steel 316L

This pressure switch has better corrosion resistance that uses stainless steel 316L for the wetted parts (pressure sensor and fitting).

Note 1) Not applicable to the rated pressure –0.1 to 2 MPa specifications (ISE80H).

Note 2) A restrictor (equivalent to -X510) is installed inside the fitting. (Piping specifications A2(L) and B2(L) are excluded.)

Specifications


Model	ZSE80(F)	ISE80	
Withstand pressure	500 kPa	1.5 MPa	
Applicable fluid	Fluids do not corrode stainless steel 316		

Models other than above are the same specifications as standard.

3 Restrictor installed fitting

A restrictor is installed inside the fitting in order to improve endurance of water collision with rush inertia in the piping when adsorption is broken.

How to Order




Note 1) Not applicable for piping specifications A2(L) and B2(L).

Note 2) Sometimes does not work for suppressing the water hammer effect even if this product is used. Take other measures in such a case.

2 Lead wire length 3 m

It has a lead wire extended to 3 meters.







Series ZSE80/ISE80 Safety Instructions

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of "Caution", "Warning" or "Danger". To ensure safety, be sure to observe ISO 4414 Note 1), JIS B 8370 Note 2) and other safety practices.

■ Explanation of the Labels

Labels	Explanation of the labels		
⚠ Danger	In extreme conditions, there is a possible result of serious injury or loss of life.		
	Operator error could result in serious injury or loss of life.		
⚠ Caution	Operator error could result in injury Note 3) or equipment damage. Note 4)		

- Note 1) ISO 4414: Pneumatic fluid power General rules relating to systems
- Note 2) JIS B 8370: General Rules for Pneumatic Equipment
- Note 3) Injury indicates light wounds, burns and electrical shocks that do not require hospitalization or hospital visits for long-term medical treatment.
- Note 4) Equipment damage refers to extensive damage to the equipment and surrounding devices.

■ Selection/Handling/Applications

1. The compatibility of the pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system

Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or post analysis and/or tests to meet the specific requirements. The expected performance and safety assurance are the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalogue information with a view to giving due consideration to any possibility of equipment failure when configuring a system.

2. Only trained personnel should operate pneumatically operated machinery and equipment.

Compressed air can be dangerous if handled incorrectly. Assembly, handling or repair of pneumatic systems should be performed by trained and experienced operators. (Understanding JIS B 8370 General Rules for Pneumatic Equipment, and other safety rules are included.)

- 3. Do not service machinery/equipment or attempt to remove components until safety is confirmed.
 - 1. Inspection and maintenance of machinery/equipment should only be performed once measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When equipment is removed, confirm that safety process as mentioned above. Turn off the supply pressure for this equipment and exhaust all residual compressed air in the system, and release all the energy (liquid pressure, spring, condenser, gravity).
 - 3. Before machinery/equipment is restarted, take measures to prevent quick extension of a cylinder piston rod, etc.
- 4. If the equipment will be used in the following conditions or environment, please contact SMC first and be sure to take all necessary safety precautions.
 - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
 - 2. Installation on equipment in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverages, recreation equipment, emergency stop circuits, clutch and brake circuits in press applications, or safety equipment.
 - 3. An application which has the possibility of having negative effects on people and/on property, requiring special safety analysis.
 - 4. If the products are used in an interlock circuit, prepare a double interlock style circuit with a mechanical protection function for the prevention of a breakdown. And, examine the devices periodically if they function normally or not.

■ Exemption from Liability

- 1. SMC, its officers and employees shall be exempted from liability for any loss or damage arising out of earthquakes or fire, action by a third person, accidents, customer error with or without intention, product misuse, and any other damages caused by abnormal operating conditions.
- 2. SMC, its officers and employees shall be exempted from liability for any direct or indirect loss or damage, including consequential loss or damage, loss of profits, or loss of chance, claims, demands, proceedings, costs, expenses, awards, judgments and any other liability whatsoever including legal costs and expenses, which may be suffered or incurred, whether in tort (including negligence), contract, breach of statutory duty, equity or otherwise.
- 3. SMC is exempted from liability for any damages caused by operations not contained in the catalogues and/or instruction manuals, and operations outside of the specification range.
- 4. SMC is exempted from liability for any loss or damage whatsoever caused by malfunctions of its products when combined with other devices or software.





Series ZSE80/ISE80 Specific Product Precautions 1

Be sure to read this before handling.

Refer to back page 1 for Safety Instructions and "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Pressure Switches Precautions.

Handling

\land Warning

- Do not drop, bump, or apply excessive impacts (980 m/s²) while handling. Although the body of the sensor may not be damaged, the internal parts of the sensor could be damaged and lead to malfunction.
- The tensile strength of the cord is 49 N. Applying a greater pulling force on it can cause malfunction. When handling, hold the body of the sensor—do not dangle it from the cord.
- Do not exceed the screw-in torque of 13.6 N⋅m when connecting the pipe to the switch. Exceeding these values may cause the switch to malfunction.
- Do not use pressure sensors with corrosive and/or flammable gases or liquids.

Connection

Marning

- Incorrect wiring can damage the switch and cause a malfunction or erroneous switch output.
- 2. Connections should be done while the power is turned off.
- 3. Wire separately from power lines and high voltage lines, avoiding wiring in the same conduit with these lines. Malfunctions may occur due to noise from these other lines.
- **4.** If a commercial switching regulator is used, make sure that the F.G. terminal is grounded.


Operating Environment

Marning

- This pressure switch is CE marked; however, it is not equipped with surge protection against lightning. Lightning surge countermeasures should be applied directly to system components as necessary.
- This pressure switch does not have an explosion proof rating. Never use in the presence of an explosive gas as this may cause a serious explosion.

⚠ Caution

- Do not use this product in an environment that gives oil or solvent splash over it.
- 2. When this pressure switch is used in a place where water and dust splash on, water and dust may enter inside the switch through the atmospheric vent port. Insert a Ø4 tube (I.D. Ø2.5) into the atmospheric vent port, and bring piping of the opposite side up to the safe position to keep it from water and dust. Do not bend the tubing or close the hole of it. It causes malfunction with the measurement of positive pressure.



- * Make sure that the tubing is inserted to the end of the atmospheric vent port.
- Use SMC tubing, TU0425 (Material: Polyurethane, Tubing O.D. ø4, I.D. ø2.5).

Operating Environment

⚠ Caution

3. Some fluids may generate static electricity when resin piping is used for piping. Take measures against static electricity with equipment when this switch is used in connection with resin piping. Also, the ground should be separate from that of the units that generate strong electromagnetic noise or high frequency, otherwise, the switch can be damaged by static electricity.

Pressure Source

⚠ Warning

1. Use of poisonous and deleterious substance, corrosive or flammable gas.

The materials used for the pressure sensor and the fitting of this switch are stainless steel 630, stainless steel 304 and stainless steel 316L (made to order). Do not use fluids such as poisonous, deleterious substances and corrosive gases.

The switch is not protected against explosion. Do not use it with **flammable gases**, either.

2. Fluid compatibility

The fluid contact areas are stainless steel 630 (pressure sensor), stainless steel 304 (fitting), stainless steel 316L (pressure sensor, fittings, made to order). Use fluids that will not corrode materials.

(For the corrosiveness of a fluid, consult with the manufacturer of the fluid.)

3. Intrusion of water and drain

A pressure sensor of stainless steel diaphragm is used for this switch. The pressure sensor of this switch can be damaged by the rush inertia of water when the drain contained in the water and the air collide with the pressure sensor when vacuum is broken after vacuum adsorption is confirmed, and it may cause malfunction of the pressure indication. If there is a possibility of water or drainage getting in, narrow the diameter of the piping to the pressure switch, or make an orifice in the middle of the piping. Extra attention is needed when the rear surface piping type model is used.

4. Withstand pressure

When liquid fluids are used, rapid pressure change can be generated such as water hammer and surge pressure when a valve is turned ON/OFF.

Install a dumper or an absorber or an accumulator as a countermeasure according to the necessity.

<Piping specifications A2(L), B2(L)> Helium leakage test

Helium leakage test is conducted on the welding parts. Use a ferrule by Swagelok (Swagelok® fittings) as the TSJ fittings and packing, ground, etc. by Swagelok (VCR® fittings) as the URJ fittings. If a ferrule, packing or ground by other manufacturers is to be used, conduct a helium leakage test before using those products.

 * Swagelok® and VCR® are registered trademarks of Swagelok Company.






Series ZSE80/ISE80 Specific Product Precautions 2

Be sure to read this before handling. Refer to back page 1 for Safety Instructions and "Precautions for Handling Pneumatic Devices" (M-03-E3A) for Pressure Switches Precautions.

Mounting




1. Mounting with panel mount adapter



2. Mounting with brackets

Mount a bracket using two M3 x 5L mounting screws and install on piping. The switch can be installed horizontally depending on the installation location.



Set Pressure Range and Rated Pressure Range


∧ Caution

Set the pressure within the rated pressure range.

The set pressure range is the range of pressure that is possible to set within.

The rated pressure range is the range of pressure that satisfies the specifications (accuracy, linearity, etc.) on the switch.

Although it is possible to set a value outside the rated pressure range, the specifications will not be guaranteed even if the value stays within the set pressure range.







EUROPEAN SUBSIDIARIES:



Austria

SMC Pneumatik GmbH (Austria). Girakstrasse 8, A-2100 Korneuburg Phone: +43 2262-62280. Fax: +43 2262-62285 E-mail: office@smc.at http://www.smc.at



Belaium

SMC Pneumatics N.V./S.A. Nijverheidsstraat 20, B-2160 Wommelgem Phone: +32 (0)3-355-1464, Fax: +32 (0)3-355-1466 E-mail: post@smcpneumatics.be http://www.smcpneumatics.be



Bulgaria

SMC Industrial Automation Bulgaria EOOD 16 kliment Ohridski Blvd., fl.13 BG-1756 Sofia Phone:+359 2 9744492, Fax:+359 2 9744519 E-mail: office@smc.bg http://www.smc.bg



Croatia

SMC Industrijska automatika d.o.o. Crnomerec 12, 10000 ZAGREB Phone: +385 1 377 66 74, Fax: +385 1 377 66 74 E-mail: office@smc.hr http://www.smc.hr



Czech Republic

SMC Industrial Automation CZ s.r.o. Hudcova 78a, CZ-61200 Brno Phone: +420 5 414 24611, Fax: +420 5 412 18034 E-mail: office@smc.cz http://www.smc.cz



Denmark

SMC Pneumatik A/S Knudsminde 4B, DK-8300 Odder Phone: +45 70252900, Fax: +45 70252901 E-mail: smc@smc-pneumatik.dk http://www.smcdk.com



Estonia

SMC Pneumatics Estonia OÜ Laki 12, 106 21 Tallinn Phone: +372 6510370, Fax: +372 65110371 E-mail: smc@smcpneumatics.ee http://www.smcpneumatics.ee



Finland

SMC Pneumatics Finland Oy PL72, Tiistinniityntie 4, SF-02231 ESPOO Phone: +358 207 513513, Fax: +358 207 513595 E-mail: smcfi@smc.fi http://www.smc.fi



France

http://www.smc-france.fr

SMC Pneumatique, S.A. Jacob Phedinial de Strasbourg, Parc Gustave Eiffel Bussy Saint Georges F-77607 Mame La Vallee Cedex 3 Phone: +33 (0)1-6476 1000, Fax: +33 (0)1-6476 1010 E-mail: contact@smc-france.fr



Germany

SMC Pneumatik GmbH Boschring 13-15, D-63329 Egelsbach Phone: +49 (0)6103-4020, Fax: +49 (0)6103-402139 E-mail: info@smc-pneumatik.de http://www.smc-pneumatik.de



Greece

SMC Hellas EPE Anagenniseos 7-9 - P.C. 14342. N. Philadelphia, Athens Phone: +30-210-2717265, Fax: +30-210-2717766 E-mail: sales@smchellas.gr http://www.smchellas.gr



Hungary

SMC Hungary Ipari Automatizálási Kft. Budafoki ut 107-113, H-1117 Budapest Phone: +36 1 371 1343, Fax: +36 1 371 1344 E-mail: office@smc.hu http://www.smc.hu



Ireland

SMC Pneumatics (Ireland) Ltd. 2002 Citywest Business Campus, Naas Road, Saggart, Co. Dublin Phone: +353 (0)1-403 9000, Fax: +353 (0)1-464-0500 E-mail: sales@smcpneumatics.ie http://www.smcpneumatics.ie



Italy

SMC Italia S.p.A Via Garibaldi 62, I-20061Carugate, (Milano) Phone: +39 (0)2-92711, Fax: +39 (0)2-9271365 E-mail: mailbox@smcitalia.it http://www.smcitalia.it



Latvia

SMC Pneumatics Latvia SIA Smerla 1-705, Riga LV-1006 Phone: +371 781-77-00, Fax: +371 781-77-01 E-mail: info@smclv.lv http://www.smclv.lv



Lithuania

SMC Pneumatics Lietuva, UAB Oslo g.1, LT-04123 Vilnius Phone: +370 5 264 81 26 Fax: +370 5 264 81 26



Netherlands

SMC Pneumatics BV De Ruyterkade 120, NL-1011 AB Amsterdam Phone: +31 (0)20-5318888, Fax: +31 (0)20-5318880 E-mail: info@smcpneumatics.nl http://www.smcpneumatics.nl

Spain

E-mail: post@smc.smces.es http://www.smces.es

Sweden

Switzerland

Turkey

http://www.smcpneumatics.co.uk

E-mail: smc@entek.com.tr

http://www.entek.com.tr

UK

Sweden AB

SMC Pneumatics Sweden AB

Ekhagsvägen 29-31, S-141 71 Huddinge

Phone: +46 (0)8-603 12 00, Fax: +46 (0)8-603 12 90

E-mail: post@smcpneumatics.se

Switzerland SMC Pneumatik AG Dorfstrasse 7, CH-8484 Weisslingen Phone: +41 (0)52-396-3131, Fax: +41 (0)52-396-3191 E-mail: info@smc.ch

Entek Pnömatik San. ve Tic. A*. Perpa Ticaret Merkezi B Blok Kat: 11 No: 1625, TR-34386, Okmeydani, Islanbul Phone: +90 (0)212-444-0762, Fax: +90 (0)212-221-1519

SMC Pneumatics (UK) Ltd Vincent Avenue, Crownhill, Milton Keynes, MK8 0AN Phone: +44 (0)800 1382930 Fax: +44 (0)1908-555064 E-mail: sales@smcpneumatics.co.uk

Zuazobidea 14, 01015 Vitoria Phone: +34 945-184 100, Fax: +34 945-184 124

SMC España, S.A.

http://www.smc.nu

http://www.smc.ch



Norway

SMC Pneumatics Norway A/S Vollsveien 13 C, Granfos Næringspark N-1366 Lysaker Tel: +47 67 12 90 20, Fax: +47 67 12 90 21 E-mail: post@smc-norge.no http://www.smc-norge.no



Poland

Poland SMC Industrial Automation Polska Sp.z.o.o. ul. Poloneza 89, PL-02-826 Warszawa, Phone: +48 22 211 9600, Fax: +48 22 211 9617 E-mail: office@smc.pl http://www.smc.pl



Portugal SMC Sucursal Portugal, S.A. Rua de Engº Ferreira Dias 452, 4100-246 Porto Phone: +351 22-610-89-22, Fax: +351 22-610-89-36 E-mail: postpt@smc.smces.es http://www.smces.es



Romania

SMC Romania srl Str Frunzei 29, Sector 2, Bucharest Phone: +40 213205111, Fax: +40 213261489 E-mail: smcromania@smcromania.ro http://www.smcromania.ro



Russia

SMC Pneumatik LLC. AB Sverdlovskaja nab, St. Petersburg 195009 Phone.:+7 812 718 5445, Fax:+7 812 718 5449 E-mail: info@smc-pneumatik.ru http://www.smc-pneumatik.ru



Slovakia

SMC Priemyselná Automatizáciá, s.r.o. Námestie Matina Benku 10, SK-81107 Bratislava Phone: +421 2 444 56725. Fax: +421 2 444 56028 E-mail: office@smc.sk http://www.smc.sk



Slovenia

SMC industrijska Avtomatika d.o.o. Mirnska cestá 7, SLO-8210 Trebnje Phone: +386 7 3885412 Fax: +386 7 3885435 E-mail: office@smc.si http://www.smc.si



OTHER SUBSIDIARIES WORLDWIDE:

ARGENTINA, AUSTRALIA, BOLIVIA, BRASIL, CANADA, CHILE, CHINA, HONG KONG, INDIA, INDONESIA, MALAYSIA, MEXICO, NEW ZEALAND, PHILIPPINES, SINGAPORE, SOUTH KOREA, TAIWAN, THAILAND, USA, VENEZUELA

> http://www.smc.eu http://www.smcworld.com

